



## Installation instructions for DD8L Series Wall Mounting Brackets

You will need:

- Spirit level
- Eight screws suitable for the surface and environment
- Screwdriver suitable for your screws
- A second pair of hands will be useful
- The two brackets, the larger bracket is the lower bracket



Before you start to use the brackets please ensure the following to prevent the water from leaking out the dehumidifier.



- The wall/bulkhead must be a smooth surface
- The wall/bulkhead must be plumb (vertically)
- The bracket must be mounted horizontally (horizontal)
- Dehumidifier must have good access to air on all sides
- you need at least 30 cm of space on all sides of the dehumidifier, particularly for the air inlet and the air outlet..
- Make sure that loose objects such as curtains do not fall onto the dehumidifier.
- The dehumidifier must be installed with the air inlet pointing into the room.



### Installation

- Find a suitable location for the dehumidifier that meets the above requirements.
- Fix the lower bracket horizontally with four screws, we recommend the use of raw plugs.
- Place the dehumidifier in the lower bracket, and make sure to keep it horizontal.
- With the dehumidifier standing in the lower bracket, mount the upper bracket so that it keeps the dehumidifier in place.



(The upper bracket must be fixed with a little downward pressure to keep the dehumidifier in position. This is especially important when mounting the movable objects such as boats, caravans etc.)